

SECTION 10 . . RIDE CONTROL UNIT

To remove the ride control unit it is unnecessary to take the gearbox out of the car or to drain the oil. There are two types of ride control unit, both fitted to the gearbox in a similar manner but they are not interchangeable due to the differences in internal design which also affects the servo drive shaft. When it becomes necessary to renew a part or a complete unit, reference should be made to the spares schedule for details concerning type, model and permissible interchangeability.

REMOVAL FROM GEARBOX

Disconnect and remove the ride control operating lever complete with its bracket.

Disconnect the flexible outlet pipe and remove the two nuts and spring washers securing the suction pipe flange. If the gearbox is being stripped for overhaul the suction pipe should be completely removed. On early gearboxes this pipe will have already been disconnected when removing the sump but on later models

the pipe must be disconnected at the two bolt flange where it passes through the side of the gearbox case.

Remove the four setscrews retaining the pump to the gearbox and withdraw the pump, disconnecting the suction pipe if not already removed. Care should be taken not to drop the drive key or pump gears during this operation.

Unscrew the two remaining setscrews retaining the intermediate plate ; the plate will be forced out by the pressure of the three dished spring washers which pre-load the drive shaft bearings. Remove the plate, distance piece and washers.

DISMANTLING

Remove the ride control valve plunger assembly by unscrewing the retaining guide (fig. 1). Unscrew and remove the outlet adapter from the opposite end ; the ball valve and spring can then be removed from either end. It is unnecessary to dismantle the control




Fig. 1 Ride control unit dismantled




Fig. 2 Control valve plunger assembly

valve plunger assembly further, unless damage or wear necessitates renewal; in such cases the retaining collar (fig. 2) must be removed and a new one fitted upon re-assembly.

INSPECTION

Thoroughly clean all parts and remove all traces of jointing compound using a suitable solvent.

Check all joint faces for burrs and damage marks. If the damage is slight remove by light scraping.

Examine the gear pockets for scoring and picking up. If severe, renew the pump body.

Check the gear teeth for damage and the gear shafts and driving dogs for wear. Renew any part which is badly worn or damaged.

Examine all alloy parts for cracks, especially in the vicinity of bolt holes and drillings.

Examine the drive key for wear and damage.




Fig. 3 Pump casing

Inspect the control valve ball and seating for pitting and grooving.

Check the size of the bore of the pump intake passage (fig. 3) and if it is found to be only $\frac{1}{4}$ in. it should be enlarged to $\frac{11}{32}$ in. as described in the following paragraph. The enlarging of this passage assists in preventing air locks.




Fig. 4 Refitting intermediate plate

First drill out with a $\frac{5}{16}$ in. drill and then finish off with an $\frac{11}{32}$ in. drill. To enable the drill to enter the hole centrally it may be necessary to relieve the shoulder on the pump flange using a round file. Care must be taken to see that the drill does not penetrate too far beyond the end of the drilling, as damage to the threads of the control valve nut may result. Clean off any swarf and blow out with compressed air.

ASSEMBLING

Re-assemble the pump control valve, fitting the outlet adapter first ; then the ball, spring and plunger assembly

from the opposite end in that order. New joint washers should be fitted under both the plunger retaining guide and the outlet adapter.

REFITTING TO THE GEARBOX

The following sequence of operations is necessary to ensure correct engagement of the driving key.

- (1) Temporarily refit the intermediate plate with the distance piece and dished-spring washers as shown in fig. 4. Fully tighten both the securing setscrews.
- (2) Rotate the drive shaft until the slot from the key is horizontal.
- (3) Insert the driving key, and pressing it fully home measure the clearance between the end of the driving blade and the outer surface of the intermediate plate (fig. 5).

This should lie between 0.020 in. and 0.040 in. If outside these limits, the outer face of the intermediate plate should be faced off accordingly or the plate changed to one of suitable thickness (see Spares schedule).

After the correct clearance is obtained remove the intermediate plate and lightly smear the gearbox joint face with jointing compound.

Refit the dished spring washers, using white grease to hold them in position. Then fit the intermediate plate together with the distance piece and finger tighten the retaining setscrews. Care should be taken to ensure that the dished washers do not slip out of position and become trapped between the gearbox casing and the intermediate plate.

Lubricate the pump gears with clean gearbox fluid and refit them to the pump body turning them so that the driving slot will mate with the key during assembly.




Fig. 5 Checking driving key clearance

Smear the pump body joint face lightly with jointing compound and then offer it into position, engaging the driving key and fitting the securing setscrews to finger tightness. Before finally tightening the setscrews, push the pump body towards the front of the gearbox as far as the clearance of the setscrew holes will permit. This method of positioning the pump is most important as it ensures a correct face seal between the gears and the intermediate plate.

Refit the sump to ride pump oil pipe, and when in position check that the inlet end of the pipe projects one inch from the sump joint face. Reposition if necessary by bending the pipe.

Refit the ride control operating lever and bracket and the flexible outlet pipe, ensuring that the latter is kept well clear of the exhaust pipe.

Finally prime the pump as described in Chapter 2.