
C7 - 23

Section C7

System test and fault diagnosis

Servo fault diagnosis Fig. C42 Sheet 1 of 4

. . .



Workshop Manual

Chapter C

C7 - 25

Section C7

System test and fault diagnosis

Servo fault diagnosis

Sheet 2 of 4

Fig. C42 continued

e seessale

Section C7

System test and fault diagnosis

Servo fault diagnosis

Sheet 3 of 4

Fig. C42 continued

0

Workshop Manual

Chapter C


C7 - 29

Section C7


System test and fault diagnosis

Servo fault diagnosis Fig. C42 continued Sheet 4 of 4


. . .



Fan and compressor relay



Fan switch-off relay right-hand drive cars. For left-hand drive cars, see Section C4.



Toeboard socket (engine side)

