

Electrical system

Contents	Sections					
	Silver Spirit Mulsanne	Silver Spur	Mulsanne Turbo	Bentley Eight	Bentley Turbo R	Corniche/ Continental
General information	M1	M1	M1	M1	M1	M1
Relays	M2	M2	M2	M2	M2	M2
Power distribution system	M3	M3	M3	M3	M3	M3
Starting system	M4	M4	M4	M4	M4	—
Ignition system	M5	M5	M5	M5	M5	M5
Charging system	M6	M6	—	—	—	—
Gearchange actuator	M7	M7	M7	M7	M7	M7
Speed control system	M8	M8	M8	M8	M8	M8
Windscreen wipers and washers	M9	M9	M9	M9	M9	M9
Fog lamps	M10	M10	M10	—	—	—
Headlamps	M11	M11	M11	M11	M11	M11
Headlamp wipers and washers	M12	M12	M12	M12	—	M12
Headlamps power wash	M12/1	M12/1	M12/1	M12/1	M12/1	—
Direction indicators and Hazard warning system	M13	M13	M13	M13	M13	M13
Stop, reversing, side/position and tail lamps	M14	M14	M14	M14	M14	M14
Interior lamps and seat belts warning	M15	M15	M15	M15	M15	M15
Panel lamps	M16	M16	M16	M16	M16	M16
Warning lamps and instruments	M17	M17	M17	—	—	—
Cigar lighters and Fuel filler door release	M18	M18	M18	M18	M18	M18
Audio equipment	M19	M19	M19	—	—	M19
Front seats	M20	M20	M20	M20	M20	M20
Centralized door locking system	M21	M21	M21	M21	M21	M21
Window lifts and division glass lift	M22	M22	M22	M22	M22	M22
Rear view door mirrors	M23	M23	M23	M23	M23	M23
Door mirror heaters and rear window demist	M23/1	M23/1	M23/1	—	M23/1	M23/1
Horns	M24	M24	M24	M24	M24	M24
Power operated hood	—	—	—	—	—	M25
Cellular telephone	—	M26	—	—	—	M26
Special torque tightening figures	—	—	—	—	—	—
Workshop tools	M28	M28	M28	M28	M28	M28
Applicable only to Silver Spur limousine	—	M29	—	—	—	—