

Direction indicators and Hazard warning system

Contents	Pages					
	Silver Spirit Mulsanne	Silver Spur	Mulsanne Turbo	Bentley Eight	Bentley Turbo R	Corniche/ Continental
Component location	M13-3	M13-3	M13-3	M13-3	M13-3	M13-3
Wiring diagram	M13-5	M13-5	M13-5	M13-5	M13-5	M13-7

Direction indicators and Hazard warning system

Silver Spirit, Silver Spur, Mulsanne
(including Turbo), and Corniche

Component location

Direction indicators and Hazard warning system

Silver Spirit, Silver Spur, and Mulsanne
(including Turbo)

Wiring diagram

Direction indicators and Hazard warning system

Corniche

Wiring diagram

