

Stop, reversing, side/position, and tail lamps




Contents	Pages					
	Silver Spirit Mulsanne	Silver Spur	Mulsanne Turbo	Bentley Eight	Bentley Turbo R	Corniche/ Continental
Stop lamps and reversing lamps <i>Excluding 1986 model year cars conforming to a North American specification</i>						
Component location	M14-3	M14-3	M14-3	M14-3	M14-3	M14-15
Wiring diagram						
Right-hand drive cars	M14-5	M14-5	M14-5	M14-5	M14-5	M14-17
Left-hand drive cars	M14-7	M14-7	M14-7	M14-7	M14-7	M14-17
1986 model year cars conforming to a North American specification						
Component location	M14-7/1	M14-7/1	—	—	—	M14-17/1
Wiring diagram	M14-7/3	M14-7/3	—	—	—	M14-17/3
Side/position and tail lamps						
Component location	M14-9	M14-9	M14-9	M14-9	M14-9	M14-19
Wiring diagram						
Right-hand drive cars	M14-11	M14-11	M14-11	M14-11	M14-11	—
Left-hand drive cars	M14-13	M14-13	M14-13	M14-13	M14-13	—
Corniche cars other than those conforming to a North American specification	—	—	—	—	—	M14-21
Corniche cars conforming to a North American specification	—	—	—	—	—	M14-23















Stop lamps and reversing lamps

Wiring diagram and components location



The stop lamps items 35 and 36 are only fitted on cars conforming to a North American specification.






Stop lamps and reversing lamps

Right-hand drive cars

Wiring diagram and component location



Stop lamps and reversing lamps


Left-hand drive cars


Wiring diagram and component location

Side/position and tail lamps

Left-hand drive cars

Wiring diagram and component location
















Stop lamps and reversing lamps

Corniche

Component location




1. Headrest
2. Seat
3. Headrest
4. Headrest
5. Headrest
6. Headrest
7. Headrest
8. Headrest
9. Headrest
10. Headrest
11. Headrest
12. Headrest
13. Headrest
14. Headrest
15. Headrest



Stop lamps and reversing lamps

Corniche

Wiring diagram

















Stop lamps and reversing lamps

Corniche/Continental

Cars conforming to a North American
specification

Component location




Stop lamps and reversing lamps

Corniche/Continental

Cars conforming to a North American
specification

Wiring diagram



Side/position and tail lamps

Corniche

Component location

